

The AccuRain Watering System




Figure 1

A Typical AccuRain System Layout


- Each head can cover a 60' diameter circle – 2800 square feet of coverage!
- As few as 6 heads can cover this 80' x 120' lot.
- Fewer heads, less pipe, easier to install!

Look closer

Figure 2

One Watering Head - Up to 15 Zones

- Each watering head can have as many as 15 separate zones.
- Zones can be almost any shape or any size.
- Each zone can have an independent schedule of watering days, and each can receive a different amount of water.



Look closer




Figure 3

Defining a Zone

- The zone is set by using the AccuRain Controller to outline the area you want to water by setting from 3-24 reference points.
- AccuRain fills in the outlined area, applying a stream of water evenly throughout the zone.
- Zones can be added, deleted, or modified at any time.